

TRIPLE S *Customs*

NISSAN QUEST 1993-2005 VEHICLE WIRING

WIRING INFORMATION: 1993 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
SECOND STARTER WIRE	RED/GREEN	Ignition Harness
IGNITION WIRE	WHITE/RED	Ignition Harness
ACCESSORY WIRE	WHITE/GREEN	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/WHITE	Harness In Driver's Kick Panel Or Behind Center Console
POWER DOOR UNLOCK (-)	GREEN/ORANGE	Harness In Driver's Kick Panel Or Behind Center Console
PARKING LIGHTS (+)	PINK	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
Wire rests at ground through door ajar indicator on dash- must use a diode to isolate. On models with OEM keyless entry there is a BLUE wire in a harness behind the center console		
REAR HATCH TRIGGER (-)	PURPLE or BROWN/WHITE	Harness In Driver's Kick Panel
TACHOMETER WIRE	GREEN	Ignition Module On Engine
BRAKE WIRE (+)	YELLOW/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	In Driver's Door
LEFT FRONT WINDOW DOWN	PURPLE	In Driver's Door
RIGHT FRONT WINDOW UP	ORANGE/BLACK	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	In Driver's Door
RIGHT REAR WINDOW DOWN	RED	In Driver's Door

WIRING INFORMATION: 1994 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
SECOND STARTER WIRE	RED/GREEN	Ignition Harness
IGNITION WIRE	WHITE/RED	Ignition Harness
ACCESSORY WIRE	WHITE/GREEN	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/WHITE	Harness In Driver's Kick Panel Or Behind Center Console
POWER DOOR UNLOCK (-)	GREEN/ORANGE	Harness In Driver's Kick Panel Or Behind Center Console
PARKING LIGHTS (+)	PINK	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
Wire rests at ground through door ajar indicator on dash- must use a diode to isolate. On models with OEM keyless entry there is a BLUE wire in a harness behind the center console		
REAR HATCH TRIGGER	Tied in with doors	
TACHOMETER WIRE	GREEN	Ignition Module On Engine
BRAKE WIRE (+)	YELLOW/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	In Driver's Door
LEFT FRONT WINDOW DOWN	PURPLE	In Driver's Door
RIGHT FRONT WINDOW UP	ORANGE/BLACK	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	In Driver's Door
RIGHT REAR WINDOW DOWN	RED	In Driver's Door

WIRING INFORMATION: 1995 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
SECOND STARTER WIRE	RED/GREEN	Ignition Harness
IGNITION WIRE	WHITE/RED	Ignition Harness
ACCESSORY WIRE	WHITE/GREEN	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/WHITE	Harness In Driver's Kick Panel Or Behind Center Console
POWER DOOR UNLOCK (-)	GREEN/ORANGE	Harness In Driver's Kick Panel Or Behind Center Console
PARKING LIGHTS (+)	PINK	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
Wire rests at ground through door ajar indicator on dash- must use a diode to isolate. On models with OEM keyless entry there is a BLUE wire in a harness behind the center console		
REAR HATCH TRIGGER	Tied in with doors	
TACHOMETER WIRE	GREEN	Ignition Module On Engine
BRAKE WIRE (+)	YELLOW/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	In Driver's Door
LEFT FRONT WINDOW DOWN	PURPLE	In Driver's Door
RIGHT FRONT WINDOW UP	ORANGE/BLACK	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	In Driver's Door
RIGHT REAR WINDOW DOWN	RED	In Driver's Door

WIRING INFORMATION: 1996 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
SECOND STARTER WIRE	WHITE/BLUE	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
SECOND IGNITION WIRE	RED/GREEN	Ignition Harness
ACCESSORY WIRE	WHITE/GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/WHITE	Harness In Driver's Kick Panel Or Behind Center Console
POWER DOOR UNLOCK (-)	GREEN/ORANGE	Harness In Driver's Kick Panel Or Behind Center Console
PARKING LIGHTS (+)	PINK/BLUE or PINK/WHITE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
Wire rests at ground through door ajar indicator on dash- must use a diode to isolate. On models with OEM keyless entry there is a BLUE wire in a harness behind the center console		
REAR HATCH TRIGGER (-)	LT.BROWN/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	RED	Harness In Driver's Kick Panel Or Behind Center Console
FACTORY ALARM DISARM (-)	RED/BLACK	Harness In Driver's Kick Panel Or Behind Center Console
TACHOMETER WIRE	GREEN	Ignition Module On Engine
BRAKE WIRE (+)	YELLOW/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	In Driver's Door
LEFT FRONT WINDOW DOWN	PURPLE	In Driver's Door
RIGHT FRONT WINDOW UP	ORANGE/BLACK	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	In Driver's Door
RIGHT REAR WINDOW DOWN	RED	In Driver's Door

WIRING INFORMATION: 1997 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
SECOND STARTER WIRE	WHITE/BLUE	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
SECOND IGNITION WIRE	RED/GREEN	Ignition Harness
ACCESSORY WIRE	WHITE/GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/WHITE	Harness In Driver's Kick Panel Or Behind Center Console
POWER DOOR UNLOCK (-)	GREEN/ORANGE	Harness In Driver's Kick Panel Or Behind Center Console
PARKING LIGHTS (+)	PINK/BLUE or PINK/WHITE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
Wire rests at ground through door ajar indicator on dash- must use a diode to isolate. On models with OEM keyless entry there is a BLUE wire in a harness behind the center console		
REAR HATCH TRIGGER (-)	LT.BROWN/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	RED	Harness In Driver's Kick Panel Or Behind Center Console
FACTORY ALARM DISARM (-)	RED/BLACK	Harness In Driver's Kick Panel Or Behind Center Console
TACHOMETER WIRE	GREEN	Ignition Module On Engine
BRAKE WIRE (+)	YELLOW/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	In Driver's Door
LEFT FRONT WINDOW DOWN	PURPLE	In Driver's Door
RIGHT FRONT WINDOW UP	ORANGE/BLACK	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	In Driver's Door
RIGHT REAR WINDOW DOWN	RED	In Driver's Door

WIRING INFORMATION: 1998 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
SECOND STARTER WIRE	WHITE/BLUE	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
SECOND IGNITION WIRE	RED/GREEN	Ignition Harness
ACCESSORY WIRE	WHITE/GREEN	Ignition Harness
POWER DOOR LOCK (-)	GREEN/WHITE	Harness In Driver's Kick Panel Or Behind Center Console
POWER DOOR UNLOCK (-)	GREEN/ORANGE	Harness In Driver's Kick Panel Or Behind Center Console
PARKING LIGHTS (+)	PINK/BLUE or PINK/WHITE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
Wire rests at ground through door ajar indicator on dash- must use a diode to isolate. On models with OEM keyless entry there is a BLUE wire in a harness behind the center console		
REAR HATCH TRIGGER (-)	LT.BROWN/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM (-)	RED	Harness In Driver's Kick Panel Or Behind Center Console
FACTORY ALARM DISARM (-)	RED/BLACK	Harness In Driver's Kick Panel Or Behind Center Console
TACHOMETER WIRE	GREEN	Ignition Module On Engine
BRAKE WIRE (+)	YELLOW/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	In Driver's Door
LEFT FRONT WINDOW DOWN	PURPLE	In Driver's Door
RIGHT FRONT WINDOW UP	ORANGE/BLACK	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/BLUE	In Driver's Door
RIGHT REAR WINDOW DOWN	RED	In Driver's Door

WIRING INFORMATION: 1999 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/GREEN	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
POWER DOOR LOCK (-)	RED	Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-) **requires a double pulse**	RED/BLACK	Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	DO NOT USE	DO NOT USE
PARKING LIGHTS (-)	GRAY/RED	At Headlight Switch
DOOR TRIGGER WIRE (-)	RED (driver door) RED/WHITE (pass. door) RED/GREEN (sliding doors)	Harness In Driver's Kick Harness In Pass. Kick Harness In Pass. Kick
DOMELIGHT SUPERVISION (-)	BROWN/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER WIRE (-)	RED/WHITE	Harness In Driver's Kick Panel
HOOD PIN (-)	BLACK/PINK	Harness Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	SINGLE PULSE TO THE UNLOCK WIRE WILL DISARM OEM SECURITY WITHOUT UNLOCKING DOORS	
TACHOMETER	WHITE	Powertrain Control Module Behind Glove Box
BRAKE WIRE (+)	YELLOW/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	LT.BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2000 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/GREEN	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
POWER DOOR LOCK (-)	RED	Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/BLACK	Harness Coming Into Vehicle From Driver's Door
Unlock requires a double pulse		
PARKING LIGHTS (+)	DO NOT USE	DO NOT USE
PARKING LIGHTS (-)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER WIRE (-)	RED	Harness In Driver's Kick
PASSENGER FRONT DOOR TRIGGER WIRE (-)	RED/WHITE	Harness In Passenger Kick Panel
SLIDING DOORS TRIGGER WIRE (-)	RED/GREEN	Harness In Passenger Kick Panel
DOMELIGHT SUPERVISION (-)	BROWN/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER WIRE (-)	RED/WHITE	Harness In Driver's Kick Panel
HOOD PIN (-)	BLACK/PINK	Harness Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	SINGLE PULSE TO THE UNLOCK WIRE WILL DISARM OEM SECURITY WITHOUT UNLOCKING DOORS	
TACHOMETER	WHITE	Powertrain Control Module Behind Glove Box
BRAKE WIRE (+)	YELLOW/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	LT.BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2001 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/GREEN	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
POWER DOOR LOCK (-)	RED	Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/BLACK	Harness Coming Into Vehicle From Driver's Door
Unlock requires a double pulse		
PARKING LIGHTS (+)	DO NOT USE	DO NOT USE
PARKING LIGHTS (-)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER WIRE (-)	RED	Harness In Driver's Kick
PASSENGER FRONT DOOR TRIGGER WIRE (-)	RED/WHITE	Harness In Passenger Kick Panel
SLIDING DOORS TRIGGER WIRE (-)	RED/GREEN	Harness In Passenger Kick Panel
DOMELIGHT SUPERVISION (-)	BROWN/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER WIRE (-)	RED/WHITE	Harness In Driver's Kick Panel
HOOD PIN (-)	BLACK/PINK	Harness Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	SINGLE PULSE TO THE UNLOCK WIRE WILL DISARM OEM SECURITY WITHOUT UNLOCKING DOORS	
TACHOMETER	WHITE	Powertrain Control Module Behind Glove Box
BRAKE WIRE (+)	YELLOW/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	LT.BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2002 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/GREEN	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
POWER DOOR LOCK (-)	RED	Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/BLACK	Harness Coming Into Vehicle From Driver's Door
Unlock requires a double pulse		
PARKING LIGHTS (+)	DO NOT USE	DO NOT USE
PARKING LIGHTS (-)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER WIRE (-)	RED	Harness In Driver's Kick
PASSENGER FRONT DOOR TRIGGER WIRE (-)	RED/WHITE	Harness In Passenger Kick Panel
SLIDING DOORS TRIGGER WIRE (-)	RED/GREEN	Harness In Passenger Kick Panel
DOMELIGHT SUPERVISION (-)	BROWN/WHITE	Harness In Driver's Kick Panel
REAR HATCH TRIGGER WIRE (-)	RED/WHITE	Harness In Driver's Kick Panel
HOOD PIN (-)	BLACK/PINK	Harness Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	SINGLE PULSE TO THE UNLOCK WIRE WILL DISARM OEM SECURITY WITHOUT UNLOCKING DOORS	
TACHOMETER	WHITE	Powertrain Control Module Behind Glove Box
BRAKE WIRE (+)	YELLOW/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	LT.BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2004 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE	Module In Driver's Door
POWER DOOR UNLOCK (-)	RED	Module In Driver's Door
Unlock requires a double pulse		
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
LEFT FRONT DOOR TRIGGER WIRE (-)	GRAY/RED	At Module Under Driver's Side Dash In Small White Connector
RIGHT FRONT DOOR TRIGGER (-)	GRAY/BLUE	At Module Under Driver's Side Dash In Large White Connector
LEFT SLIDING DOOR TRIGGER WIRE (-)	WHITE/GREEN	At Module Under Driver's Side Dash In Small White Connector
RIGHT SLIDING DOOR TRIGGER WIRE (-)	ORANGE/BLACK or RED/WHITE	At Module Under Driver's Side Dash In Large White Connector
REAR HATCH TRIGGER WIRE (-)	ORANGE	At Module Under Driver's Side Dash In Small White Connector
POWER LIFTGATE (-)	GREEN/RED	In Driver's "A" Pillar
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	SINGLE PULSE TO THE UNLOCK WIRE WILL DISARM OEM SECURITY WITHOUT UNLOCKING DOORS	
TACHOMETER	NOT BLACK or RED	Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will roll the windows up or down	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
This vehicle is equipped with an Immobilizer that must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Nissan Quest

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE	Module In Driver's Door
POWER DOOR UNLOCK (-)	RED	Module In Driver's Door
Unlock requires a double pulse		
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
LEFT FRONT DOOR TRIGGER WIRE (-)	GRAY/RED	At Module Under Driver's Side Dash In Small White Connector
RIGHT FRONT DOOR TRIGGER (-)	GRAY/BLUE	At Module Under Driver's Side Dash In Large White Connector
LEFT SLIDING DOOR TRIGGER WIRE (-)	WHITE/GREEN	At Module Under Driver's Side Dash In Small White Connector
RIGHT SLIDING DOOR TRIGGER WIRE (-)	ORANGE/BLACK or RED/WHITE	At Module Under Driver's Side Dash In Large White Connector
REAR HATCH TRIGGER WIRE (-)	ORANGE	At Module Under Driver's Side Dash In Small White Connector
POWER LIFTGATE (-)	GREEN/RED	In Driver's "A" Pillar
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	SINGLE PULSE TO THE UNLOCK WIRE WILL DISARM OEM SECURITY WITHOUT UNLOCKING DOORS	
TACHOMETER	NOT BLACK or RED	Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will roll the windows up or down	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
This vehicle is equipped with an Immobilizer that must be bypassed when installing a remote start system.		