

TRIPLE S *Customs*

**TOYOTA COROLLA 1984-2006
VEHICLE WIRING**

WIRING INFORMATION: 1984 Toyota Corolla FWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER	COMMON WITH DOORS	(Hatchback Only)
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	GREEN/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1985 Toyota Corolla FWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER	COMMON WITH DOORS	(Hatchback Only)
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	GREEN/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1986 Toyota Corolla FWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER	COMMON WITH DOORS	(Hatchback Only)
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	GREEN/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1987 Toyota Corolla FWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER	COMMON WITH DOORS	(Hatchback Only)
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	GREEN/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1984 Toyota Corolla RWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1985 Toyota Corolla RWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1986 Toyota Corolla RWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1987 Toyota Corolla RWD

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE OR BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	DK. GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LT. GREEN	Harness At Steering Column
HEADLIGHTS (-)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	RED/WHT OR BLK/WHT	Harness At Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1988 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	DK.GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE or BLACK	Harness At Fuse Box Or Factory Anti-Theft Unit In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM ARM (-)	WHITE or BLUE/YELLOW	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM DISARM (-)	WHITE/GREEN or BLUE/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1989 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	DK.GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE or BLACK	Harness At Fuse Box Or Factory Anti-Theft Unit In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM ARM (-)	WHITE or BLUE/YELLOW	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM DISARM (-)	WHITE/GREEN or BLUE/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1990 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	DK.GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE or BLACK	Harness At Fuse Box Or Factory Anti-Theft Unit In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM ARM (-)	WHITE or BLUE/YELLOW	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM DISARM (-)	WHITE/GREEN or BLUE/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1991 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	DK.GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE or BLACK	Harness At Fuse Box Or Factory Anti-Theft Unit In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM ARM (-)	WHITE or BLUE/YELLOW	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM DISARM (-)	WHITE/GREEN or BLUE/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1992 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	DK.GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE or BLACK	Harness At Fuse Box Or Factory Anti-Theft Unit In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM ARM (-)	WHITE or BLUE/YELLOW	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
FACTORY ALARM DISARM (-)	WHITE/GREEN or BLUE/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Unit In Passenger Kick Panel
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1993 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE or BLACK	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Dimmer Switch Or Harness In Driver Kick Panel
POWER DOOR LOCK (-)	BLUE/BLACK	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED or GREEN/WHITE	Harness In Passenger Kick Panel
DOOR TRIGGER (-)	For door trigger wire, use BLACK in a connector at the top of the fuse box on vehicles without a factory sunroof. On vehicles with a factory sunroof use the RED/WHITE wire in a connector at the top of the fuse box.	
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Connector At Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1994 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE or BLACK	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Dimmer Switch Or Harness In Driver Kick Panel
POWER DOOR LOCK (-)	BLUE/BLACK	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED or GREEN/WHITE	Harness In Passenger Kick Panel
DOOR TRIGGER (-)	For door trigger wire, use BLACK in a connector at the top of the fuse box on vehicles without a factory sunroof. On vehicles with a factory sunroof use the RED/WHITE wire in a connector at the top of the fuse box.	
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Connector At Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1995 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE or BLACK	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Dimmer Switch Or Harness In Driver Kick Panel
POWER DOOR LOCK (-)	BLUE/BLACK	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED or GREEN/WHITE	Harness In Passenger Kick Panel
DOOR TRIGGER (-)	For door trigger wire, use BLACK in a connector at the top of the fuse box on vehicles without a factory sunroof. On vehicles with a factory sunroof use the RED/WHITE wire in a connector at the top of the fuse box.	
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Connector At Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1996 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE or BLACK	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Dimmer Switch Or Harness In Driver Kick Panel
POWER DOOR LOCK (-)	BLUE/BLACK	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED or GREEN/WHITE	Harness In Passenger Kick Panel
DOOR TRIGGER (-)	For door trigger wire, use BLACK in a connector at the top of the fuse box on vehicles without a factory sunroof. On vehicles with a factory sunroof use the RED/WHITE wire in a connector at the top of the fuse box.	
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Connector At Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1997 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE or BLACK	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	GREEN	At Dimmer Switch Or Harness In Driver Kick Panel
POWER DOOR LOCK (-)	BLUE/BLACK	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/RED or GREEN/WHITE	Harness In Passenger Kick Panel
DOOR TRIGGER (-)	For door trigger wire, use BLACK in a connector at the top of the fuse box on vehicles without a factory sunroof. On vehicles with a factory sunroof use the RED/WHITE wire in a connector at the top of the fuse box.	
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Connector At Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1998 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-)	GREEN/WHITE	Connector On Right Side Of Fuse Box
Test door lock wires by using the key in the passenger door.		
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1999 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-)	GREEN/WHITE	Connector On Right Side Of Fuse Box
Test door lock wires by using the key in the passenger door.		
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2000 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-)	GREEN/WHITE	Connector On Right Side Of Fuse Box
Test door lock wires by using the key in the passenger door.		
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2001 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-)	GREEN/WHITE	Connector On Right Side Of Fuse Box
Test door lock wires by using the key in the passenger door.		
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2002 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-)	GREEN/WHITE	Connector On Right Side Of Fuse Box
Test door lock wires by using the key in the passenger door.		
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2003 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE/BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	GREEN	Blue Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Blue Connector In Driver's Kick Panel
Test door lock wires by using the key in the driver door. Unlock requires a double pulse.		
DOOR TRIGGER (-)	RED/WHITE	At Interior Light Switch
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER	BLACK	At ECM behind Glove Box In Right Plug
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2004 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE/BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	GREEN	Blue Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Blue Connector In Driver's Kick Panel
Test door lock wires by using the key in the driver door. Unlock requires a double pulse.		
DOOR TRIGGER (-)	RED/WHITE	At Interior Light Switch
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER	BLACK	At ECM behind Glove Box In Right Plug
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2005 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE/BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	GREEN	Blue Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Blue Connector In Driver's Kick Panel
Test door lock wires by using the key in the driver door. Unlock requires a double pulse.		
DOOR TRIGGER (-)	RED/WHITE	At Interior Light Switch
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER	BLACK	At ECM behind Glove Box In Right Plug
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2006 Toyota Corolla

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE/BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	GREEN	Blue Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Blue Connector In Driver's Kick Panel
Test door lock wires by using the key in the driver door. Unlock requires a double pulse.		
DOOR TRIGGER (-)	RED/WHITE	At Interior Light Switch
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER	BLACK	At ECM behind Glove Box In Right Plug
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		